



# Thank you

for downloading this pdf file from [Knitting-and.com](http://Knitting-and.com)!

Your visits have helped keep Knitting-and.com online, providing free crafts and recipes since 1996.

There are hundreds of free patterns and crafts available and more added all the time!

**Note:** The pink watermark on the following pages will not show if you print this file.

# Singercraft Guide.

## INSTRUCTIONS TO REMOVE AND ATTACH THE KNIFE.




Fig. 1

1. Knife Guard
2. Knife
3. Frame
4. Spacing Piece




Fig. 2

### <http://www.knitting.com> To remove the knife and guard.

Hold frame in left hand, as illustrated, and, with the thumb and forefinger of the right hand, twist circular part of the knife towards you and push same to the left.

## To attach the knife.




Fig. 3

Attach knife to guard, as illustrated.




Fig. 4

Hold knife and guard in the right hand and the frame in the left hand, in the manner illustrated above. Place the frame over the studs as shown in Fig. 5, and move the forefinger of the right hand to the right.




Fig. 5

<https://www.knitting-and.com>

**THE SINGER MANUFACTURING CO.**